# D1 6 Button Switch

Easy to use

D1 6 button switch is a classic and practical product, it can be custom-ized by the user to one-click control of the light or light group. The dimming button can also be used to adjust the change of light or light group

Highly customizable

The D1 6 button switch gives direct access to all the important Casambi lighting control functionalities. The preset buttons of D1 6 button switch can be configured via the Casambi App.


COLOR

Starlight gold PC/AG glass	Phantom gray PC/AG glass	Mica white PC/AG glass	Lava gray Art glass	Lava white Art glass

---

TECHNICAL PARAMETER

Product size	86 x 86 x 10.5
Bottom shell depth	28mm
Package size	100 x 100 x 60 mm
Weight	0.13 kg
Gross weight	0.18 kg
Installation mode	86 Mounting box depth：>50mm

Input voltage	110-240VAC 50/60Hz
Network mode	Bluetooth Casambi
Material	PC/AG Glass
Fire rating	94-v0
Working temperature	-10℃～+60℃
Working humidity	≤95%RH，Non-condensing

Size Specification

57.8mm

10.5mm

28mm

60mm

86mm

86mm

Wiring Instruction

L

N

Load

N   L2 L1 L

■ Blue（Load）
■ Red（Live wire）
■ Black（Neutral wire）

Button Settings Instruction

Double – click the device to enter the editing page.

XD1PN1L-Lighting_FINAL   SI-D1CB103   XD1CB1L

Xxx1780   M-BMPN-01   D1 6 Button Switch

1   2
3   4
5   6

The buttons corresponding to the APP.

Select the button that needs to be edited.

< Back   D1 6 Button Switch

luminaires and nearby luminaires.

MODES

Default   Mode 1   Mode 2   Mode 3

Tap to activate a mode and hold to edit settings

PUSH BUTTONS

1   Not in use   >

2   Not in use   >

3   Not in use   >

4   Not in use   >

5   Not in use   >

6   Not in use   >

Controls what happens when a push button is used.

Use toggle

Tapping the button will switch the configured target between OFF and ON (100% or last dim level).

Dedicated daylight sensor   >

Selects the dedicated daylight sensor for this luminaire.

The button can be bound to the following functions.

< Back   Push buttons

Not in use   ✓
The push button has no special effect.

Controls a luminaire
Tap to turn a luminaire on or off - hold to adjust luminaire brightness.

Controls an element
Tap to turn a device element on or off - hold to adjust the element value.

Controls a group
Tap to turn a group ON or OFF - hold to adjust brightness.

Control scene
Tap to turn a scene on or off - hold to adjust scene brightness.

Controls all luminaires
Tap to turn all luminaires ON or OFF - hold to adjust brightness.

Controls priority
Toggles scenes with control priority on activation and deactivation.

BASIC FUNCTIONS

The preset buttons of D1 Remote Ccontrol can be configured via the Casambi app. A light indicates the selected preset.

Dim up, Dim down:

• Smooth dimming of last chosen preset

Preset buttons:

• Individual luminaire control

• Group control

• Control of all luminaires

• Recall scenes

• Recall animations

Preset button ---- 1 · · 2 ---- Preset button

Preset button ---- 3 · · 4 ---- Preset button

Preset button ---- 5 · · 6 ---- Preset button

SMART FUNCTIONS

Dimming

• Hold the Dim down or Dim up button:

    Smooth dimming of last chosen preset, cycle takes 5 seconds

• Press the Dim down button:

    Chosen preset goes to 0%

• Press the Dim up button:

    Chosen preset goes to 100%

Preset Buttons

• Press:

    The chosen preset (luminaire control, group control, all luminaires, scene recall or animation recall) will turn on

• Press again:

    The chosen preset (luminaire control, group control, all luminaires, scene recall or animation recall) will turn off

Turn Off

• Press the Dim down and Dim up button for more than 1 second:

    Turns all luminaires off in selected network

Relay

• Up to 2 relays will provide on/off circuit breaker function